




WWB222324 Watch Winder Motor Replacement

wwb2+2, wwb2+4, wwb2+3

Written By: easy_source



INTRODUCTION

Instructions to replace winder motor and gear assembly.



TOOLS:


- [Phillips #0 Screwdriver](#) (1)



PARTS:

- [Watch Winder Motor & Gear Assembly](#) (1)

Step 1 — Motor




- Turn the winder off
- Unplug the power cord

Step 2




- Pull angled turntable platform toward you by upper seam

Step 3




- Unplug motor connection cable from circuit board

Step 4



- Unscrew two retaining screws from gearbox
- Remove round watch insert
- Unscrew single retaining screw from cup

Step 5



- Pull gearbox and motor out from back of the turntable platform
- Follow steps in reverse order to replace motor

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-08-10 11:28:27 AM.